



High speed data transfer to Windows PC/Mac based Nonlinear Editor  
Install the P2 drive into a 5 type bay on a desktop PC  
With the AC adaptor, you can use it as a stand-alone external drive  
PCI Express Interface  
Please click here for a list of operation manuals to download.

## AJ-PCD35

P2 Card Drive with Five P2 card Slots and High Speed PCI Express Interface

### Key Features

---

High speed data transfer

---

Able for use as a stand-alone drive

---

PCI Express Interface



## AJ-PCD35

<https://eu.connect.panasonic.com/dk/en/products/broadcast-proav/aj-pcd35>

<b>Power Source</b>	DC 16 V 0.6 A with AC adaptor, DC 12 V 0.8 A when PC built-in
<b>AC Adapter</b>	AC 100 V to 240 V (1.20 A), 50 Hz/60 Hz
<b>Weight</b>	approx. 1.2 kg (2.6 lb)
<b>Dimensions (W x H x D)</b>	148.4 mm x 42.5 mm x 199.5 mm, excluding protruding parts (5-7/8 inches x 1-11/16 inches x 7-7/8 inches)
<b>PC System Requirement</b>	Microsoft Windows 7 Professional (SP1), Ultimate (SP1) 32 bit/64 bit Microsoft Windows Vista Business (SP1, SP2), Ultimate (SP1, SP2) 32 bit/64 bit Microsoft Windows XP Professional (SP2, SP3) 32 bit Mac OS X 10.4, 10.5, 10.6, 10.7, 10.8 (Intel® based Mac) 1 GB or more memory