



Compact, easy-to-operate remote controller

## AW-RP50

Camera Control Unit

### Key Features

Up to 5 cameras/pan-tilt heads may be controlled via serial connection

Multi-control: Up to 5 x AW-RP50 can simultaneously control one remote camera unit

Up to 100 pre-set memories are available per camera

Various settings can be configured from a PC (configuration software supplied)

Up to 100 remote camera units may be controlled via IP and Ethernet hubs



## AW-RP50

<https://eu.connect.panasonic.com/gb/en/broadcast-proav/aw-rp50>

<b>Power Supply</b>	DC 12 V ±10 % (AC adaptor provided)
<b>Power Consumption</b>	0.5 A (With DC1 2V)
<b>Weight</b>	Approx. 1.1 kg (Approx.2.4 lbs)
<b>Dimensions (W x H x D)</b>	210 mm x 67 mm x 177 mm (8-1/4 inches x 2-9/16 inches x 6-15/16 inches) (excluding protrusions)
<b>Accessory</b>	AC Adaptor, Power cable
<b>Protocol</b>	IPv4, RS-422 ( Panasonic AW series protocol)
<b>LAN</b>	10BASE-T/100BASE-TX (for IP control)RJ45 x 1
<b>Operating Temperature</b>	0 °C to 40 °C
<b>Operating Humidity</b>	10 % to 90 % ( no condensation)
<b>Connection</b>	IP : 1
<b>Adjustment Functions</b>	Pan/Tilt, Zoom, Focus, Iris, Gain, Pedestal, Shutter, Detail, White Balance ( Auto, R/B Gain), Black Balance ( Auto, R/B Pedestal), Switch scene files
<b>Preset Memory</b>	Up to 100 sets
<b>Switcher Supported</b>	AW-HS50
<b>Linkage</b>	Camera information display, Tally information imported, Bus material selection (AUX/PWW/PinP/KEY-F), Parameter Changes ( Pan/Tilt lever, Zoom button)
<b>T0 Pan/Tilt Head</b>	RS-422 (for Serial control)/RJ45 x 5
<b>Tally/GPI</b>	TALLY INPUT x 5 channels GPI INPUT x 4 channels GPI OUTPUT x 4 channels/D-sub 15 pin (female) x 1