



Jednostka sterowania kamerą

AW-RP50 Wszechstronne sterowanie kamerami i łatwa obsługa

Kompaktowy i łatwy w obsłudze kontroler zdalny

Key Features

Za pomocą połączenia szeregowego można sterować nawet pięcioma kamerami/głowicami obrotowo-uchylnymi

Sterowanie wieloma urządzeniami: Jedną jednostką kamery zdalnej może sterować maksymalnie pięć sterowników AW-RP50

Maksymalnie 100 ustawień wstępnych na kamerę

Sterowanie maksymalnie 100 jednostkami kamer zdalnych za pośrednictwem koncentratorów IP lub Ethernet

Ustawienia można konfigurować na komputerze (zestaw zawiera odpowiednie oprogramowanie)



AW-RP50

Wszechstronne
sterowanie
kamerami i łatwa
obsługa

<https://eu.connect.panasonic.com/pl/pl/products/broadcast-proav/aw-rp50-wszechstronne-sterowanie-kamerami-i-latwa-obsługa>

Power Supply	DC 12 V ±10 % (AC adaptor provided)
Power Consumption	0.5 A (With DC1 2V)
Weight	Approx. 1.1 kg (Approx.2.4 lbs)
Dimensions (W x H x D)	210 mm x 67 mm x 177 mm (8-1/4 inches x 2-9/16 inches x 6-15/16 inches) (excluding protrusions)
Accessory	AC Adaptor, Power cable
Protocol	IPv4, RS-422 (Panasonic AW series protocol)
LAN	10BASE-T/100BASE-TX (for IP control)/RJ45 x 1
Operating Temperature	0 °C to 40 °C
Operating Humidity	10 % to 90 % (no condensation)
Connection	IP : 1
Adjustment Functions	Pan/Tilt, Zoom, Focus, Iris, Gain, Pedestal, Shutter, Detail, White Balance (Auto, R/B Gain), Black Balance (Auto, R/B Pedestal), Switch scene files
Preset Memory	Up to 100 sets
Switcher Supported	AW-HS50
Linkage	Camera information display, Tally information imported, Bus material selection (AUX/PWW/PinP/KEY-F), Parameter Changes (Pan/Tilt lever, Zoom button)
T0 Pan/Tilt Head	RS-422 (for Serial control)/RJ45 x 5
Tally/GPI	TALLY INPUT x 5 channels GPI INPUT x 4 channels GPI OUTPUT x 4 channels/D-sub 15 pin (female) x 1